


This quickstart guide provides a brief overview of the e-Shower, safety instructions and daily use. For full instructions, refer to the installation manual and the extensive user manual.

You can request them from www.hamwells.com/en/order

e-Shower

e-Shower wall model (reservoir)*



*Displayed e-Shower is just one example of the different e-Shower options. The size of the shower column remains the same with each option.

Technical specifications

Dimensions technical cabinet: 2142 mm (L) x 280 mm (B) x 220 mm (D)

Weight: 30 kilo

Max. power consumption: 500W

Power supply: 240V/50Hz

RCD: 30mA

Algemene beschrijving e-Shower (fig.1)

- | | |
|-----------------------|------------------------------|
| 1. Rain shower | 6. Service drawer |
| 2. Handshower | 7. Bottom panel |
| 3. Display | 8. SmartStop |
| 4. Touch buttons | 9. Filter |
| 5. Rotary push button | 10. Reservoir of shower tray |





Safety instructions

If there are signs of damage or the shower is not working properly, turn off the e-Shower by pressing the the rotary push button and please contact your vendor.

- New users, who do not know how to use the e-Shower must be instructed.
- Never attempt to repair, disassemble or make modifications to this product. The e-Shower contains live parts. Contact with these parts can cause an electric shock.
- Only qualified engineers should carry out repair and maintenance with original replacements with the prior written approval of the manufacturer.
- Always supervise children and incapacitated persons during use of the e-shower.
- Before each use of the e-Shower, check the temperature setting of the water.
- If you have a baby bath filled with the handshower, check the water with a thermometer whether the water has the right temperature!
- The hand shower always gives tap water. The water used in the FreshCycles (from the rain shower) is continuously filtered, purified and refreshed. However, the quality of the water depends on the user's behavior and hygiene.
- It is advisable not to drink water from rain shower.
- Always consult your own general practitioner with allergies, open wounds and the risk of infections, skin problems or any health worries before using the FreshCycles.

Operation of the e-Shower



1





Start the e-Shower
The Classic Shower mode is the default mode.

!
You always can switch between Classic Shower and FreshCycles.

2



Select the desired temperature
The temperature lock is set at 38 °C. Press the bottom right button to unlock the temperature lock.





3



Select handshower
Short session to wash and rinse off.

4



Select FreshCycles
*FreshCycles is preparing...
Enjoy the water and energy saving session.*


5




Stop FreshCycles
The e-Shower will automatically go off.

6


1



2



3



Clean the filter after every shower session **!** *You can use a small brush.*

Contact your vendor:



Hamwells®

Thames 9, 3144 DG Maassluis, the Netherlands

T +31 85 303 6496, E info@hamwells.com,

I www.hamwells.com, @hamwells

© 2017 Hamwells Europe B.V. All rights reserved.